



OEMStar™ QUICK REFERENCE GUIDE

Precise thinking

NovAtel Format Commands

Command	Syntax and Example Input(s)	ID	Tag	Description
ADJUST1PPS	<code>adjust1pps mode [period] [offset]</code> <code>adjust1pps mark</code>	429		Adjust receiver clock or transfer time between receivers
ANTENNA-POWER	<code>antennapower flag</code> <code>antennapower on</code>	98		Enable/disable power from receiver's internal power source to the low-noise amplifier of an active antenna

Command	Syntax and Example Input(s)	ID	Tag	Description
ASSIGN	assign channel [state] prn [Doppler [window]] assign 6 28 -250 0 <i>(sv channel 6 is acquiring satellite prn 28 at an offset of 250 hz only)</i> <i>(prn 1 to 32 for gps channels, 38 to 61 for glonass, and 120 to 138 for sbas)</i>	27		Aids in initial acquisition of a satellite by allowing you to override the automatic satellite/channel assignment reacquisition processes
ASSIGNALL	assignall [system] [state] prn [Doppler [window]] assignall gpsl1 28 -250 0 <i>(L1 dedicated sv channels trying to acquire satellite prn 28 at -250 hz)</i>	28		This command works the same way as ASSIGN except that it affects all SV channels
AUTH	auth [state] part1 part2 part3 part4 part5 model [date] auth add 1234 5678 9abc def0 1234 lxgbdrrmts 990131	49		Add or remove authorization codes from the receiver

Command	Syntax and Example Input(s)	ID	Tag	Description
BASE- ANTENNA- MODEL	antennamodel name SN setupID type [L1 offset] [L1 var] antennamodel NVH05410007 1 user	870		Enter or change a base antenna model. For the rover, see the ANTENNAMODEL command
CLOCK- ADJUST	clockadjust switch clockadjust disable	15		Enable receiver clock steering.
CLOCK- CALIBRATE	clockcalibrate mode [period] [width] [slope] [bandwidth] clockcalibrate auto	430		Adjust the control parameters of the clock steering loop
CLOCK- OFFSET	clockoffset offset clockoffset -15	596		Remove a delay in the PPS output
CNOUPDATE	cnoupdate rate cnoupdate 20hz	849		C/No update rate and resolution

Command	Syntax and Example Input(s)	ID	Tag	Description
COM	com [port] bps [parity [databits [stopbits [handshake [echo[break]]]]]] com com1 57600 n 8 1 n off on	4		Configure the receiver asynchronous serial port drivers
COM-CONTROL	comcontrol port signal control comcontrol com2 rts default	431		Control the hardware control lines of the RS232 ports
CSMOOTH	csmooth L1time csmooth 500	269		Set carrier smoothing on code measurements
DATUM	datum datum datum csrs	160		Select a datum
DGPSEPH-DELAY	dgpsephemdelay delay dgpsephemdelay 120	142		Set base station ephemeris delay
DGPSTIME-OUT	dgpstimeout delay dgpstimeout 60	127		Set rover station max. age of pseudorange differential data

Command	Syntax and Example Input(s)	ID	Tag	Description
DGPSTXID	dgpstxid type ID dgpstxid rtcm 2 dgpstxid rtca d036	144		Set station ID value for the receiver when it is transmitting corrections
DYNAMICS	dynamics dynamics dynamics foot	258		Adjust receiver to match environment
ECUTOFF	ecutoff angle ecutoff 10.0	50		Set elevation cut-off angle for satellites
FIX	fix type [param1 [param2 [param3]]] fix height 4.567	44		Fix parameters such as height or position
FIXPOS-DATUM	fixposdatum datum [lat [lon [height]]] fixposdatum user 51.11633810554 -114.03839550586 1048.2343	761		Set position by referencing parameters through a specified datum

Command	Syntax and Example Input(s)	ID	Tag	Description
FREQUENCY-OUT	frequencyout [switch] [pulsewidth] [period] frequencyout enable 2 4 <i>(to generate a 50% duty cycle 10 mhz square wave)</i>	232		Set output pulse train available on the VARF pin (variable frequency)
FRESET	freset [target] freset command	20		Clear data which is stored in non-volatile memory
GGA-QUALITY	ggaquality [#entries] [pos type1] [qual1] [pos type2] [qual2]... ggaquality 2 waas 2	691		Customize NMEA GPGGA GPS quality indicator
GLO-CSMOOTH	glocsmooth L1time glocsmooth 200	830	GLO	Carrier smoothing for GLONASS channels
GLO-ECUTOFF	gloecutoff angle gloecutoff 15.0	735	GLO	Set elevation cut-off angle for tracked GLONASS satellites

Command	Syntax and Example Input(s)	ID	Tag	Description
INTERFACE-MODE	interfacemode [port] rxtype txtype [responses] interfacemode com1 rtca novatel on	3		Specify what type of data a particular port on the receiver can transmit and receive
LOCKOUT	lockout prn lockout 8 <i>(prn 1 to 32 for gps channels, 38 to 61 for glonass, and 120 to 138 for sbas)</i>	137		Prevent receiver from using a satellite by de-weighting its range in the solution
LOG	log [port] message [trigger [period[offset [hold]]]] log com1 bestposa ontime 7 2.5 hold	1		Log data using several different methods of triggering the log events
MAGVAR	magvar type [correction [stddev]] magvar correction 15 0	180		Navigate in agreement with magnetic compass bearings

Command	Syntax and Example Input(s)	ID	Tag	Description
MARK-CONTROL	markcontrol signal switch [polarity] [timebias [timeguard]] markcontrol mark1 enable negative 50 100	614		Control processing of mark 1 (MK1I) inputs
MODEL	model model model lxxmts	22		Switch receiver models previously added with the AUTH command
NMEA-TALKER	nmeatalker ID nmeatalker gp	861		Set NMEA talker ID: gp (GPS only) or auto (GPS or GLO)
NVM-RESTORE	nvmrestore nvmrestore	197		Restore non-volatile memory (NVM)
PDPFILTER	pdpfilter switch pdpfilter enable (see Configurations in OM-20000126)	424		Enable pseudorange /delta phase (PDP) filter (normal or GL1DE®)

Command	Syntax and Example Input(s)	ID	Tag	Description
PDPMODE	<p>pdpmode mode dynamics</p> <p>pdpmode relative dynamic</p>	970		Select the PDP mode: normal or relative (GLIDE)
POSAVE	<p>posave [state] maxt [maxhstd [maxvstd]]</p> <p>posave 24 1 2</p>	173		Implement base station position averaging
POS-TIMEOUT	<p>postimeout sec</p> <p>postimeout 1200</p>	612		Set the time out value for the position calculation(s)
PPS-CONTROL	<p>ppscontrol switch [polarity] [rate]</p> <p>ppscontrol enable positive 0.05</p>	613		Control polarity and rate of PPS output

Command	Syntax and Example Input(s)	ID	Tag	Description
PSRDIFF-SOURCE	<pre>psrdiffsource type ID rtksource rtkcm any psrdiffsource rtkcm any sbascontrol enable auto</pre> <p><i>(to enable psrdiff from rtkcm, with an sbas fall-back)</i></p>	493		Identify from which base station to accept differential corrections <i>(see also rtksource)</i>
PSR-VELOCITY-TYPE	<pre>psrvelocitytype [source] psrvelocitytype doppler</pre>	950		Set Doppler source for velocities determined by pseudorange filter
RESET	<pre>reset [delay] reset 120</pre>	18		Perform a hardware reset
RTKSOURCE	<pre>RTKSOURCE type ID rtksource rtkmv3 5 rtksource rtkcm 6</pre>	494	DGPS_ Rx_ Advanced	Set the RTK correction source

Command	Syntax and Example Input(s)	ID	Tag	Description
SAVECONFIG	saveconfig <i>(in cdu, ensure you have all windows, other than the console window, closed before using this command)</i>	19		Save present configuration in NVM
SBAS-CONTROL	sbascontrol keyword [system] [prn] [testmode] sbascontrol enable waas 0 zerototwo	652	SBAS	Set handling of SBAS corrections
SELECT-CHAN-CONFIG	selectchanconfig [set] selectchanconfig 2	1149		Change the types of signals tracked
SEND	send port data send com1 "log com1 rtcaobs ontime 5"	177		Send ASCII printable data from a COMUSB port to a specified port
SENDHEX	sendhex port length data sendhex com1 6 143ab5910d0a	178		Send non-printable characters expressed as hexadecimal pairs

Command	Syntax and Example Input(s)	ID	Tag	Description
SETAPPROX-POS	setapproxpos lat lon height setapproxpos 51.116 -114.038 0	377		Set an approximate latitude, longitude, and height in the receiver
SETAPPROX-TIME	setapproxtime week sec	102		Set an approximate time in the receiver
SET-BESTPOS-CRITERIA	setbestposcriteria type delay setbestposcriteria pos2d 5	839		Set criteria for the BESTPOS log
SETIONO-TYPE	setionotype model setionotype klobuchar	711		Set the ionospheric model for the receiver
SETNAV	setnav from-lat from-lon to-lat to-lon track offset from-point to-point setnav 51.1516 -114.16263 51.16263 -114.1516 -125.23 start finish	162		Enter a set of navigation waypoints

Command	Syntax and Example Input(s)	ID	Tag	Description
SETRTCM16	setrtcm16 text setrtcm16 "base station will shut down in 1 hour"	131		Transfer ASCII text from a base to a rover
SETRTCM36	setrtcm36 extdtext setrtcm36 "quick \d166\d146\d174\d144\d140"	880	GLO	Enter ASCII text that includes Cyrillic or Russian characters. e.g. "quick ШТОРМ"
SETUTCLEAP SECONDS	setutcleapseconds [seconds] setutcleapseconds 15	1150		Used to calculate UTC time
STATUS- CONFIG	statusconfig type word mask statusconfig set status 0028a51d	95		Configure status mask fields in the RXSTATUSEVENT log
UNASSIGN	unassign channel unassign 11	29		Cancel a previously issued ASSIGN command

Command	Syntax and Example Input(s)	ID	Tag	Description
UNASSIGN-ALL	unassignall [system] unassignall gps11	30		Cancel previous ASSIGN commands for all SV channels
UNDULATION	undulation option [separation] undulation user -5.5999999 <i>or</i> undulation table	214		Enter a specific geoidal undulation value or use the internal table of geoidal undulations
UNLOCKOUT	unlockout prn unlockout 8 <i>(prn 1 to 32 for gps channels, 38 to 61 for glonass, and 120 to 138 for sbas)</i>	138		Reinstate a previously locked out satellite
UNLOCKOUT-ALL	unlockoutall unlockoutall	139		Reinstate all previously locked out satellites
UNLOG	unlog [port] datatype unlog com1 bestposa	36		Remove a specific log request from system
UNLOGALL	unlogall [port] unlogall com2	38		Disable all logs on the specified port only

Command	Syntax and Example Input(s)	ID	Tag	Description
USERDATUM	<pre> userdatum semimajor flattening dx dy dz rx ry rz scale userdatum 6378206.400 294.97869820000 - 12.0000 147.0000 192.0000 0.0000 0.0000 0.0000 0.0000000000 </pre>	78		Enter customized ellipsoidal datum parameters

Command	Syntax and Example Input(s)	ID	Tag	Description
USEREXP-DATUM	<pre> userexpdatum semimajor flattening dx dy dz rx ry rz scale xvel yvel zvel xrvel yrvel zrvel scalev refdate userexpdatum 6378137.000 298.25722356280 0.000000000 0.000000000 0.000000000 0.000000000 0 0.000000000 0.000000000 0.000000000 0.000000000 0.000000000 0.000000000 0.0000 00000 0.000000000 0.000000000 0.000000000 0.000000000 </pre>	783		Enter customized ellipsoidal expanded datum parameters
UTMZONE	<pre> utmzone command parameter utmzone set 10 </pre>	749		Set UTM persistence, zone #, or meridian
WAAS-ECUTOFF	<pre> waasecutoff angle waasecutoff -2 </pre>	505	SBAS	Set SBAS satellites' elevation cut-off angle

Command	Syntax and Example Input(s)	ID	Tag	Description
WAAS-TIMEOUT	waastimeout set [delay] waastimeout set 100 <i>(the auto default is 180 s)</i>	851	SBAS	Set amount of time receiver remains in an SBAS position if it stops receiving SBAS

NovAtel Format Logs

Log	Description and fields after header	ID	Tag	Input Example
ALMANAC	Current GPS almanac info #msgs, prn, week, seconds, ecc, ω , ω_0 , ω , mo, afo, afl, n, a, inc-angle, sv config, hlth-prn, hlth-alm, antspf, next prn...	73		log almanaca onchanged

Log	Description and fields after header	ID	Tag	Input Example
AVEPOS	Position averaging lat, lon, ht, lat σ , lon σ , hgt σ , posave, ave time, samples	172		log aveposa onchanged
BESTPOS	Position data sol status, pos type, lat, lon, hgt, undulation, datum id#, lat σ , lon σ , hgt σ , stn id, diff_age, sol_age, #SV, #solnSV, #gg11, rsrvd, rsrvd, ext sol stat, rsrvd, sig mask	42		log bestposa ontime 1

Log	Description and fields after header	ID	Tag	Input Example
BESTUTM	Best available UTM data sol status, pos type, z#, zletter, northing, easting, hgt, undulation, datum id#, n σ , e σ , hgt σ , stn id, diff_age, sol_age, #SV, #solnSV, #ggl1, rsvrd, rsvrd, ext sol stat, rsvrd, sig mask	726		log bestutma ontime 1
BESTVEL	Velocity data sol status, vel type, latency, age, hor spd, trk gnd, vert spd, rsvrd	99		log bestvela ontime 1

Log	Description and fields after header	ID	Tag	Input Example
BESTXYZ	Cartesian coord pos p-solstat, p-type, p-x, p-y, p-z, p-x σ , p-y σ , p-z σ , v-solstat, v-type, v-x, v-y, v-z, v-x σ , v-y σ , v-z σ , stnid, v-latency, diff_age, sol_age, #SV, #solnSV, #ggll, rsrvd, rsvrd, ext sol stat, rsvrd, sig mask	241		log bestxyza ontime 1
CHAN- CONFIGLIST	Available channel configurations set in use, num sets, channel per signal type [num sets x [num configuration x2]]	1146		log chanconfiglista once
CLOCK- MODEL	Clock model matrices clockstat, reject, noiset, updatet, params[1x3], covdata[3x3], rangebias, rangebiasrate, change	16		log clockmodela ontime 1

Log	Description and fields after header	ID	Tag	Input Example
CLOCK-STEERING	Clock steering status source, steeringstate, period, pulsewidth, bandwidth, slope, offset, driftrate	26		log clocksteeringa onchanged
COM-CONFIG	Current COM port config #ports, port, baud, parity, databits, stopbits, handshake, echo, breaks, rxtype, txtype, response	317		log comconfiga once
GLMLA	GLONASS almanac data \$glmla, #alm, alm#, slot, N, hlth & freq, ecc, ΔT_{dot} , ω , τ_{16msb} , ΔT , $t\lambda$, λ , Δi , τ_{121sb} , t	859	GLO	log glmla onchanged

Log	Description and fields after header	ID	Tag	Input Example
GLO-ALMANAC	Decoded GLONASS almanac #recs, week, time ^a , slot, freq, sat type, health, tlambda n, lambda n, delta i, ecc, arg perigee, delta t, delta td, tau, next message...	718	GLO	log gloalmanaca onchanged
GLOCLOCK	GLONASS clock information rsrvd, rsrvd, rsrvd, sat type, n4, tau gps, na, tau_c, b1, b2, kp	719	GLO	log gloclocka ontime 1

Log	Description and fields after header	ID	Tag	Input Example
GLO-EPHEMERIS	GLONASS ephemeris data sloto, freqo, sat type, rsrvd, e week, e time, t offset, Nt, rsrvd, rsrvd, issue, health, posx, posy, posz, velx, vely, velz, ls accx, ls accy, ls accz, tau_n, delta_tau_n, gamma, tk, p, ft, age, flags	723	GLO	log gloephemerisa onchanged
GLORAW-ALM	Raw GLONASS almanac week, time ^a , #recs, string, rsrvd, next rec...	720	GLO	log glorawalma onchanged
GLORAW-EPHEM	Raw GLONASS ephemeris data sloto, freqo, sigchan, week, time ^a , #recs, string, rsrvd, next rec...	792	GLO	log glorawephema onchanged

Log	Description and fields after header	ID	Tag	Input Example
GLORAW-FRAME	Raw GLONASS frame data frame#, sloto, freqo, week, time ^a , frame decode, sigchan, #recs, string, rsrvd, next rec...	721	GLO	log glorawframea onchanged
GLORAW-STRING	Raw GLONASS string data slot, freq, string, rsrvd	722	GLO	log glorawstringa onchanged
GPALM	Almanac data \$gpalm, #msgs, msg#, prn, gps wk, sv health, ecc, alm ref time, incl angle, omegadot, rt axis, omega, long asc node, m ₀ , a _{f0} , a _{f1} , next msg...	217		log gpalm onchanged

Log	Description and fields after header	ID	Tag	Input Example
GPGGA	GPS fix data and undulation \$gpgga, utc, lat, lat dir, lon, lon dir, gps qual, #sats, hdop, alt, alt units, undulation, undulation units, age, stn id	218		log gpgga ontime 1
GPGGA- LONG	Fix data and undulation with extra precision \$gpgga, utc, lat, lat dir, lon, lon dir, gps qual, #sats, hdop, alt, alt units, undulation, undulation units, age, stn id	521		log gpggalong ontime 1

Log	Description and fields after header	ID	Tag	Input Example
GPGLL ^b	Geographic position - lat/lon \$gpgll, lat, lat dir, lon, lon dir, utc, data status, mode ind	219		log gpgll ontime 1
GPGRS ^b	GPS range residuals for each satellite \$gpgrs, utc, mode, rsvrd, rsrvd, rsvrd, rsvrd, rsvrd, rsrvd, rsvrd, rsvrd, rsvrd, rsrvd, rsvrd, rsvrd	220		log gpgrs ontime 1
GPGSA ^b	GPS DOP and active satellites \$gpgsa, mode man/auto, mode 123, prn, prn, prn, prn, prn, prn, prn, prn, prn, prn, prn, prn, pdop, hdop, vdop	221		log gpgsa ontime 1

Log	Description and fields after header	ID	Tag	Input Example
GPGST ^b	Pseudorange measurement noise stats \$gpgst, utc, rms, smjr std, smnr std, orientation, lat std, lon std, alt std	222		log gpgst ontime 1
GPGSV ^b	GPS satellites in view \$gpgsv, #msgs, msg#, #sats, prn, elev, azimuth, snr, next sat...	223		log gpgsv ontime 1
GPRMB ^b	Generic navigation info \$gprmb, data status, xtrack, dir, origin id, dest id, dest lat, lat dir, dest lon, lon dir, range, bearing, vel, arr status, mode ind	224		log gprmb ontime 1

Log	Description and fields after header	ID	Tag	Input Example
GPRMC ^b	GPS specific info \$gprmc, utc, pos status, lat, lat dir, lon, lon dir, speed kn, track true, date, mag var, mag var dir, mode ind	225		log gprmc ontime 1
GPSEPHEM	GPS ephemeris data prn, tow, health, iode1, iode2, week, z week, toe, a, dn, m0, ecc, w, cuc, cus, crc, crs, cic, cis, i ₀ , i ⁰ , w ₀ , ω̇, iodc, toc, tgd, af0, af1, af2, as, n, ura	7		log gpsephema onchanged

Log	Description and fields after header	ID	Tag	Input Example
GPVTG ^b	Track made good and ground speed \$gpvtg, track true, t ind, track made good, m track ind, speed kn, n speed ind, speed km, k speed ind, mode ind	226		log gpvtg ontime 1
GPZDA	UTC time and date \$gpzda, utc, day, month, year, rsvrd, rsvrd	227		log gpzda ontime 1
IONUTC	Ionospheric/UTC info a0, a1, a2, a3, b0, b1, b2, b3, utcwn, tot, a0, a1, wnlsf, dn, deltat ls, deltat lsf, rsvrd	8		log ionutca onchanged
LOGLIST	A list of system logs #logs, port, message, message type, rsvrd, trigger, period, offset, hold, next log...	5		log loglista once

Log	Description and fields after header	ID	Tag	Input Example
MARKPOS	Position at mark in event solstat, postype, lat, lon, hgt, undulation, datumid#, lat σ , lon σ , hgt σ , stnid, diffage, solage, #SV, #solnSV, #ggl1, rsvrd, rsvrd, ext sol stat, rsvrd, sig mask	181		log markposa onnew
MARKTIME	Time of mark input event week, s, offset, offsetstd, utcoffset, status	231		log marktimea onnew
NAVIGATE	Navigation waypoint status solstat, ptype, vtype, navtype, dist, bearing, atrack, xtrack, eta wk, eta s	161		log navigatea ontime 1

Log	Description and fields after header	ID	Tag	Input Example
PASSCOMn (n=1,2) PASSUSBn (n=1,2,3)	Port pass-through logs to redirect data #bytes, data, next byte...	233- 234 607- 609		log passusb2a onchanged
PASSXCOMn (n=1,2,3)	Virtual pass-through logs redirect data <i>as passcom above</i>	405- 406, 795		log passxcom1 onchanged
PDPPOS	PDP filter position sol stat, pos type, lat, lon, hgt, undulation, datum id#, lat σ , lon σ , hgt σ , stn id, diff_age, sol_age, #sats, #sats soln, rsrvd, rsrvd, rsrvd, rsrvd, rsrvd, rsrvd	469		log pdpposa ontime 1
PDPVEL	PDP filter velocity sol stat, vel type, latency, age, hor spd, trk gnd, height, rsrvd	470		log pdpvela ontime 1

Log	Description and fields after header	ID	Tag	Input Example
PDPXYZ	PDP Cartesian position and velocity p-sol stat, pos type, p-x, p-y, p-z, p-x σ , p-y σ , p-z σ , v-sol stat, vel type, v-x, v-y, v-z, v-x σ , v-y σ , v-z σ , stn id, v-latency, diff_age, sol_age, #sats, #sats soln, rsvrd, rsvrd, rsvrd, rsvrd, rsvrd, rsvrd	471		log pdpxyza ontime 1
PORTSTATS	COM or USB port statistics #ports, port, rx chars, tx chars, acc rx chars, dropped chars, interrupts, breaks, par err, fram err, overruns, next port...	72		log portstatsa once

Log	Description and fields after header	ID	Tag	Input Example
PSRDOP	DOPs of current SVs gdop, pdop, hdop, htdop, tdop, cutoff, #prns, prn, next prn...	174		log psrdopa onchanged
PSRPOS	Pseudorange position solstat, postype, lat, lon, hgt, undltn, datumid#, lat σ , lon σ , hgt σ , stnid, diff age, sol age, #SV, #solnSV, #ggl1, rsrvd, rsvrd, ext sol stat, rsvrd, sig mask	47		log psrposa ontime 1
PSRTIME	Time offsets from pseudorange filter #recs, system, offset, offset stdv, next prn...	881		log psrtimea ontime 1
PSRVEL	Pseudorange velocity solstat, vtype, latency, age, horspd, trkgnd, vertspd, rsrvd	100		log psrvela ontime 1

Log	Description and fields after header	ID	Tag	Input Example
PSRXYZ	Pseudorange Cartesian position p-solstat, postype, p-x, p-y, p-z, p-x σ , p-y σ , p-z σ , v-solstat, v-type, v-x, v-y, v-z, v-x σ , v-y σ , v-z σ , stnid, v-latency, diff age, sol age, #SV, #solnSV, rsvrd, rsvrd, rsrvd, ext sol stat, rsvrd, sigmask	243		log psrxyza ontime 1
RANGE	Satellite range info #baseborn/slot ^c , glofreq, psr, psr std, adr, adr std, dopp, c/no, locktime, ch-tr-status, next obs...	43		log rangea ontime 30
RANGECMP	Compressed RANGE log #obs, 1st range record, next obs...	140		log rangecmpa ontime 10

Log	Description and fields after header	ID	Tag	Input Example
RAWALM	Raw almanac refweek, refsecs, #subframes, svid, data, next subframe...	74		log rawalma onchanged
RAWEPHEM	Raw ephemeris prn, refweek, refsecs, subframe1, subframe2, subframe3	41		log rawephema onchanged
RAWGPS-SUBFRAME	Raw subframe data decode#, prn, subfr id, data, chan	25		log rawgpssubframea onnew
RAWGPS-WORD	Raw navigation word prn, nav word	407		log rawgpsworda onnew
RAWWAAS-FRAME	Raw SBAS frame data decode#, prn, waas msg id, data, chan	287	SBAS	log rawwaasframea onnew

Log	Description and fields after header	ID	Tag	Input Example
RTCA1	Type 1 differential GPS corrections	10	DGPS_Tx	log com2 rtca1 ontime 10 3
RTCAEPHEM	Ephemeris and time information	347	DGPS_Tx	log com2 rtcaephem ontime 10 7
RTCM1	Type 1 differential GPS corrections	107	DGPS_Tx	log rtc1 ontime 10 3
RTCM3	Type 3 base station parameters	117	DGPS_Tx	log rtc3 ontime 10
RTCM9	Type 9 partial differential corrections	275	DGPS_Tx	log rtc9 ontime 10
RTCM15	Type 15 ionospheric corrections	307	DGPS_Tx	log rtc15 ontime 10
RTCM16	Type 16 special message	129	DGPS_Tx	log rtc16 once
RTCM23	Type 23 antenna type definition record	665	DGPS_Tx	log rtc23 ontime 5
RTCM24	Type 24 Antenna Reference Point (ARP) parameters	667	DGPS_Tx	log rtc24 ontime 5
RTCM31	Type 31 GLONASS differential corrections	864	DGPS_Tx & GLO	log rtc31 ontime 2

Log	Description and fields after header	ID	Tag	Input Example
RTCM32	Type 32 GLONASS base station parameters	873	DGPS_Tx & GLO	log rtc32 ontime 2
RTCM36	Type 36 special message	875	DGPS_Tx & GLO	log rtc36 once
RTCM59	Type 59N-0	116	DGPS_Tx	log rtc59 ontime 10
RTCM59GLO	Proprietary GLONASS differential	903	DGPS_Tx & GLO	log rtc59glo ontime 2
RXCONFIG	Receiver config status embedded header, embedded msg, embedded crc, next embedded command...	128		log rxconfiga once

Log	Description and fields after header	ID	Tag	Input Example
RXSTATUS	Self-test status error, #stats, rxstat, rxstat pri, rxstat set, rxstat clear, aux1stat, aux1stat pri, aux1stat set, aux1stat clear, aux2stat, aux2stat pri, aux2stat set, aux2stat clear, aux3stat, aux3stat pri, aux3stat set, aux3stat clear, next stat...	93		log rxstatusa onchanged
RXSTATUS- EVENT	Status event indicator status, bit pos, event, descrip	94		log rxstatuseventa onchanged

Log	Description and fields after header	ID	Tag	Input Example
SATVIS	Satellite visibility satellite visibility?, complete gps almanac?, #sats, prn/slot ^c , glofreq, health, elev, az, true dop, apparent dop, next sat...	48		log satvisa ontime 60
SATXYZ	ECEF satellite Cartesian pos rsrvd, #sats, prn/slot ^c , x, y, z, clk corr, iono corr, tropo corr, rsvrd, rsvrd, next sat...	270		log satxyza ontime 1
TIME	Receiver time information clock status, offset, offset std, utc offset, utc year, utc month, utc day, utc hour, utc min, utc ms, utc status	101		log timea ontime 1

Log	Description and fields after header	ID	Tag	Input Example
TRACKSTAT	Satellite tracking status sol status, pos type, ecutoff, #chans, prn/slot ^c , glofreq, ch-tr-status, psr, dop, cno, locktime, psr res, reject code, psr weight, next chan...	83		log trackstata ontime 1
VALID-MODELS	Receiver model/expiry date #mods, model, expyear, expmonth, expday, next mod...	206		log validmodelsa once
VERSION	Receiver version numbers #components, type, model, psn, hw version, sw version, boot version, compile date, compile time, next component...	37		log versiona once

Log	Description and fields after header	ID	Tag	Input Example
WAAS0	Which PRN to remove from solution prn	290	SBAS	log waas0a onchanged
WAAS1	PRN mask assignment prn, mask, iodp	291	SBAS	log waas1a onchanged
WAAS2	Fast corrections slots 0-12 prn, iodf, iodp, prc0, prc1, prc2, prc3, prc4, prc5, prc6, prc7, prc8, prc9, prc10, prc11, prc12, udre0, udre1, udre2, udre3, udre4, udre5, udre6, udre7, udre8, udre9, udre10, udre11, udre12	296	SBAS	log waas2a onchanged

Log	Description and fields after header	ID	Tag	Input Example
WAAS3	Fast corrections slots 13-25 prn, iodf, iodp, prc13, prc14, prc15, prc16, prc17, prc18, prc19, prc20, prc21, prc22, prc23, prc24, prc25, udre13, udre14, udre15, udre16, udre17, udre18, udre19, udre20, udre21, udre22, udre23, udre24, udre25	301	SBAS	log waas3a onchanged
WAAS4	Fast corrections slots 26-38 prn, iodf, iodp, prc26, prc27, prc28, prc29, prc30, prc31, prc32, prc33, prc34, prc35, prc36, prc37, prc38, udre26, udre27, udre28, udre29, udre30, udre31, udre32, udre33, udre34, udre35, udre36, udre37, udre38	302	SBAS	log waas4a onchanged

Log	Description and fields after header	ID	Tag	Input Example
WAAS5	Fast corrections slots 39-50 prn, iodf, iodp, prc39, prc40, prc41, prc42, prc43, prc44, prc45, prc46, prc47, prc48, prc49, prc50, prc21, udre39, udre40, udre41, udre42, udre43, udre44, udre45, udre46, udre47, udre48, udre49, udre50, udre51 (do not use)	303	SBAS	log waas5a onchanged

Log	Description and fields after header	ID	Tag	Input Example
WAAS6	Integrity message prn, iodf2, iodf3, iodf4, iodf5, udre0, udre1, udre2, udre3, udre4, udre5, udre6, udre7, udre8, udre9, udre10, udre11, udre12, udre13, udre14, udre15, udre16, udre17, udre18, udre19, udre20, udre21, udre22, udre23, udre24, udre25, udre26, udre27, udre28, udre29, udre30, udre31, udre32, udre33, udre34, udre35, udre36, udre37, udre38, udre39, udre40, udre41, udre42, udre43, udre44, udre45, udre46, udre47, udre48, udre49, udre50, udre51 (invalid)	304	SBAS	log waas6a onchanged

Log	Description and fields after header	ID	Tag	Input Example
WAAS7	Fast correction degradation prn, latency, iodp, spare bits, ai(0), ai(1), ai(2), ai(3), ai(4), ai(5), ai(6), ai(7), ai(8), ai(9), ai(10), ai(11), ai(12), ai(13), ai(14), ai(15), ai(16), ai(17), ai(18), ai(19), ai(20), ai(21), ai(22), ai(23), ai(24), ai(25), ai(26), ai(27), ai(28), ai(29), ai(30), ai(31), ai(32), ai(33), ai(34), ai(35), ai(36), ai(37), ai(38), ai(39), ai(40), ai(41), ai(42), ai(43), ai(44), ai(45), ai(46), ai(47), ai(48), ai(49), ai(50), ai(51) (invalid, do not use)	305	SBAS	log waas7a onchanged

Log	Description and fields after header	ID	Tag	Input Example
WAAS9	GEO navigation message prn, iodn, t ₀ , ura, x, y, z, xvel, yvel, zvel, xaccel, yaccel, zaccel, a _{fo} , a _{f1}	306	SBAS	log waas9a onchanged
WAAS10	Degradation factor prn, b _{rcc} , c _{1tc_1sb} , c _{1tc_v1} , i _{1tc_v1} , c _{1tc_v0} , i _{1tc_v1} , c _{geo_1sb} , c _{geo_v} , i _{geo} , c _{er} , c _{iono_step} , i _{iono} , c _{iono_ramp} , rss _{udre} , rss _{iono} , spare bits	292	SBAS	log waas10a onchanged
WAAS12	SBAS network time & UTC prn, a1, a0, seconds, week, dtls, wnlsf, dn, dtlsf, utcid, gpstow, gpswn, glo ind, rsvrd	293	SBAS	log waas12a onchanged

Log	Description and fields after header	ID	Tag	Input Example
WAAS17	GEO almanac message prn, #entries, data id, entry prn, health, x, y, z, x vel, y vel, z vel, next entry..., t ₀	294	SBAS	log waas17a onchanged
WAAS18	IGP mask prn, #bands, band#, iodi, igp mask, spare bit	295	SBAS	log waas18a onchanged
WAAS24	Mixed fast/slow corrections prn, prc0, prc1, prc2, prc3, prc4, pcr5, udre0, udrel, udre2, udre3, udre4, udre5, iodp, block id, iodf, spare, vel, mask1, iodel, dx1, dy1, dz1, da ^{f0} , mask2, iode2, ddx, ddy, ddz, da ^{f1} , t ₀ , iodp, corr spare	297	SBAS	log waas24a onchanged

Log	Description and fields after header	ID	Tag	Input Example
WAAS25	Long-term slow corrections source prn, 1st vel, 1st mask1, 1st iodel, 1st dx1, 1st dy1, 1st dz1, 1st da ^{f0} , 1st mask2, 1st iode2, 1st ddx, 1st ddy, 1st ddz, 1st da ^{f1} , 1st t ₀ , 1st iodp, 1st corr spare, 2nd vel, 2nd mask1, 2nd iodel, 2nd dx1, 2nd dy1, 2nd dz1, 2nd da ^{f0} , 2nd mask2, 2nd iode2, 2nd ddx, 2nd ddy, 2nd ddz, 2nd da ^{f1} , 2nd t ₀ , 2nd iodp, 2nd corr spare	298	SBAS	log waas25a onchanged

Log	Description and fields after header	ID	Tag	Input Example
WAAS26	iono-delay corrections prn, band#, block id, #pts, igp _{vde} , givei, next pt..., iode, spare	299	SBAS	log waas26a onchanged
WAAS27	SBAS service message prn, iods, #messages, message#, priority code, dudre inside, #regs, lat1,lon1, lat2, lon2, shape,next reg..., t ₀	300	SBAS	log waas27a onchanged
WAASCORR	SBAS range corrections use #sats,prn, iode, psr corr, corr stdv,next sat...	313	SBAS	log waascorra ontime 1

- GPS Time, in milliseconds (binary data) or seconds (ASCII data)
- If NMEATALKER is set to AUTO, the talker (the first 2 characters after the \$ in the log header) is set to GP (GPS satellites only), GL (GLONASS satellites only), or GN (both systems' satellites).
- PRN 1 to 32 for GPS channels, 38 to 61 for GLONASS, and 120 to 138 for SBAS.

© 2009-2010 NovAtel Inc. All rights reserved. Unpublished rights reserved under international copyright laws. Printed in Canada on recycled paper. Recyclable.

NovAtel and **GLIDE** are registered trademarks of NovAtel Inc.
OEMStar is a trademark of NovAtel Inc.
All other brand names are trademarks of their respective holders.

